



A CSW Industrials Company

PRODUCT DATA SHEET

NOVENT® CAP
Locking Refrigerant Caps

Description

For any gas (A2L compatible), 1/4" and 5/16" thread, key. Precision machined from high-grade brass and covered by a shielding aluminum shroud, Novent caps require special tools to be applied and removed. All caps are embossed and color-coded. Proper installation helps stop accidental refrigerant mixing in A/C systems.

Applications

Seals standard Schrader service valves on central A/C units and mini-splits to help prevent refrigerant leakage. Protects from severe injury or death resulting from the inhalation of dangerous gases.



Characteristics | Features

- Resists crushing & removal without key
- Corrosion-resistant
- Integral neoprene O-ring resists oils & sealants
- Torque limiter prevents overtightening
- A2L compatible

Packaging

Code	Size	Qty. per Case	Lbs. per Case	Cubic Feet per Case
Novent® Silver UNI				
86690 (NS-STARTPACK)	(6) UNI caps (1) Multikey 1/4"	10	3.4	0.12
86691 (NS-UNI)	10 cap blister 1/4"	10	5	0.12
86692 (NS-UNI)	2 cap blister 1/4"	20	2.5	0.19
86693 (NS-UNI)	50 cap box 1/4"	1	3	0.036
86694 (NS-UNI)	100 pack 1/4"	1	6	0.07
86695 (NS-UNI-2PK)	2 cap blister 5/16"	20	2.6	0.28
86696 (NS-UNI-10PK)	10 cap blister 5/16"	10	5	0.16
86697 (NS-UNI)	50 cap box 5/16"	1	3	0.04

NOVENT® CAP

Locking Refrigerant Caps

Code	Size	Qty. per Case	Lbs. per Case	Cubic Feet per Case
Novent® Pink R410				
86671 (NPE-R410)	10 cap blister 5/16"	5	5	0.12
86672 (NPE-R410)	2 cap blister 5/16"	20	2.5	0.19
86673 (NPE-R410)	50 cap box 5/16"	1	3	0.04
86681 (NP-R410)	10 cap blister 1/4"	10	5	0.12
86682 (NP-R410)	2 cap blister 1/4"	20	2.5	0.19
86683 (NP-R410)	50 cap box 1/4"	1	3	0.04
86684 (NP-R410)	100 pack 1/4"	1	6	0.07
Novent® Starter Pack				
86680 (NP-STARTPACK)	(6) R410A caps (1) Multikey	10	3.4	0.12
Novent® Keys				
86660 (NG-R22-SDT)	UNI & green screwdriver	20	3	0.12
86688 (NP-R410SDT)	Pink screwdriver	20	3	0.12
86698 (NVMULTIKEY)	Multikey blister	20	2	0.19

Installation

Grasp cap, insert tool and turn clockwise until snug. Install cap on service port, tighten until cap seats. Grasp cap, rotate tool counter-clockwise and remove tool. Reverse for cap removal.

WARNING: Remove cap slowly and carefully. Contents under pressure and may cause injury. Always wear eye protection. Stand to the side and away from possible cap trajectory. Check mechanical stamp on cap to identify proper refrigerant.

Precautionary Statements

Refer to Safety Data Sheet (SDS).

KEEP OUT OF REACH OF CHILDREN

FOR CHEMICAL EMERGENCY, SPILL, LEAK, FIRE, EXPOSURE OR ACCIDENT, CALL CHEMTREC - DAY OR NIGHT 1-800-424-9300

For additional Technical Information Call Toll Free 1-800-231-3345



Limited Warranty



For more information on our product warranty, visit rectorseal.com.

Manufactured by
RectorSeal® LLC

2601 Spenwick Drive • Houston, TX 77055, USA • 800-231-3345 • Fax 800-441-0051 • rectorseal.com

A CSW Industrials Company. RectorSeal, the logos and other trademarks are property of RectorSeal, LLC, its affiliates or its licensor's and are protected by copyright, trademark and other intellectual property laws, and may not be used without permission. RectorSeal reserves the right to change specifications without prior notice. ©2024 RectorSeal. All rights reserved. R50624-0824